CV_KH2220_E168_LB6.qxd 16.10.2007 9:11 Uhr Seite 1



# STAINLESS STEEL KETTLE

GB IE CY **Stainless steel kettle**
Operating instructions

KOMPERNASS GMBH · BURGSTRASSE 21 · D-44867 BOCHUM
www.kompernass.com
ID-Nr.: KH2220-09/07-V2

CV_KH2220_E168_LB6.qxd 16.10.2007 9:11 Uhr Seite 4

# KH2220

# Stainless steel kettle KH2220

Read the operating instructions carefully before using the appliance for the first time and preserve this booklet for later reference. Pass the manual on to whomsoever might acquire the appliance at a later date.

## Intended Use

- This appliance is not for commercial or outdoor use.
- The electric water kettle is exclusively suitable for heating water and may not be used for heating other liquids.

## Describtion of the appliance

1. Chute
2. Release button
3. Indicator lamp
4. On/Off switch
5. Level indicator
6. Base station
7. Kettle

## Technical Data

| | |
|---|---|
| Power supply: | 230V / 50Hz |
| Output: | 2200 Watt |
| Content: | 1.7 Litres |

## Safety instructions

- Use the electric water kettle only for the intended purpose and in accordance with this user manual.

**⚠ Danger of electrical shock**

- Make sure that the base with the electrical connections does not come into contact with water! Let the base dry completely before using, should it ever accidentally become wet.
- Make sure that the power cord never becomes wet or damp during operation. Lay the cord such that it cannot be pinched or otherwise damaged.
- Arrange for defective power plugs and/or cables to be replaced as soon as possible by a qualified technician or by our Customer Service Department to avoid the risk of injury.
- Always pull the plug out of the power socket after use. Switching off the device is not sufficient because the device receives power as long as the power plug is connected to the socket.
- Use the appliance only if the local mains voltage complies with the rated voltage of the appliance (230 V for 50 Hz).

**⚠ Fire hazard! / Risk of injury!**

- Always heat the water with a closed lid, otherwise the automatic cut out may not work. Boiling water can then spray out over the edge.
- Hot vapours may leak out and the electric water kettle may be very hot while in operation. It is always best to wear oven mitts when handling the kettle.
- Make sure that the appliance is placed on a stable and vertical base, before you switch on the appliance. Boiling water can cause an unstabile kettle to fall over.
- Do not leave a heat generating appliance unsupervised!

- Do not allow individuals (including children) to use the appliance whose physical, sensorial or mental abilities or lack of experience and knowledge hinder their safe usage of it if they have not previously been supervised or instructed in its correct usage.
- Tell children about the appliance and its potential dangers so that they do not play with it.

**You can thus prevent the appliance from being damaged**

- Use the kettle ❼ only in the base station provided for the same ❻. Do not use the base station ❻ for any other purposes.
- Do not expose the base station ❻ to any liquids and protect it from splashes.
- Do not separate the kettle ❼ from the base station ❻ while the appliance is in operation. Always switch off the appliance first.
- An improper use or handling of the appliance may lead the appliance to malfunction and cause injuries to the user.
- No liabilities shall be accepted for damages caused by improper or wrong use.

## Before the First Use

1. Remove all the packaging material!
2. Clean the kettle ❼, by pouring water into it and bringing it to a boil (See "Operation"). Pour out the water and repeat the process.

## Operation

1. Pull the power cord out only as much as is necessary. Pull it out by opening the base station ❻ and connect the plugs with an appropriate power socket.
2. Open the lid and fill in with the desired quantity of water. Please note the level indicator ❺ of the appliance.
   Fill the kettle ❼...
   - atleast up to the MIN mark, so as not to overheat the electric water kettle.
   – no higher than the MAX mark so that no boiling water spills out.
3. Close the lid and place the appliance on the base station ❻. The appliance can only be switched on if it is fixed to the base station.
4. Keep the On/Off switch ❹ on „ ☕ “- position. The appliance begins to operate, the indicator lamp ❸ begins to flash.
5. If the water is boiling the appliance switches off automatically. The On/Off switch ❹ automatically moves to the "O“ position, the indicator lamp ❸ turns off.
6. If you want to stop or interrupt the boiling process, keep the On/Off switch ❹ on the "O“ position.
   However, you can continue the boiling process by waiting for 20 seconds until the heating element has cooled off. You can then switch on the appliance once again.
   During the cooling phase, do not press the on/off switch ❹, as this can damage the appliance.
7. While the appliance is not in use, unplug the power cord from the socket, so as to prevent the appliance from an inadvertent start.

**Note:** The appliance has a safety device. This switches off the heating element, if the appliance is switched on when empty or is cooking dry. In such a condition, allow the appliance to cool off completely, before pouring in water again.
For safety reasons and to avoid injuries do not open the lid when the water is boiling or very hot.

## Cleaning

ⓘ Please follow the safety instructions as well.

⚠ Always unplug the power cord from the socket, before cleaning the appliance. Allow the kettle ❼ to cool down completely.

- Clean the outer side of the kettle and the base station with a soft, damp cloth. Do not use any abrasive materials.
- Decalcify the appliance at regular intervals. For this use a decalcifying agent available with specialised dealers.

## Disposal

**Do not dispose of the appliance in your normal domestic waste.**

Dispose of the appliance through an approved disposal centre or at your community waste facility. Observe the currently applicable regulations. In case of doubt, please contact your waste disposal centre.

Dispose of the packaging materials in an environmentally responsible manner .

## Warranty and Service

This appliance is guaranteed for 3 years from the date of purchase. It has been carefully produced and meticulously checked before delivery. Please keep your receipt as proof of purchase. Contact your service centre by telephone in case of questions pertaining to the warranty.
Your goods can be transmitted free of cost only in this manner.

The warranty covers only material or manufacturing faults, not normal wear or damage to fragile parts such as switches or rechargeable batteries. The appliance is intended solely for private, not commercial, use. If this product has been subjected to improper or inappropriate handling, abuse, or interventions not carried out by one of our authorised sales and service outlets, the warranty will be considered void. This warranty does not affect your statutory rights.

(GB) **DES Ltd**
Units 14-15
Bilston Industrial Estate
Oxford Street
Bilston
WV14 7EG
Tel.: 0870/787-6177
Fax: 0870/787-6168
e-mail: support.uk@kompernass.com

(IE) **Kompernass Service Ireland**
c/o Irish Connection
41 Harbour view
Howth Co. Dublin
Tel: 087-99 62 077
Fax: 18398056
e-mail: support.ie@kompernass.com

## Importer

KOMPERNASS GMBH
BURGSTRASSE 21
D-44867 BOCHUM
www.kompernass.com